



Remove from carry bag.





3 Swing lock arm into position.

Use rubber mallet to hammer spike into ground.



MIMPORTANT

- Drive the spike into the ground before attaching the tabletop.
- Only drive the spike by hand or with a rubber mallet.
- Do not use a hammer or rock to drive the spike as this could cause damage.
- Do not attempt to drive the spike by pushing down on the tabletop.



















MIMPORTANT

- Unscrew the tabletop before removing the spike from the ground.
- Do not attempt to remove the spike by pulling up on the tabletop.













2 Year Limited Warranty

We take pride in the quality and design of every ZEMPIRE table or cupboard, that's why our TABLES & CUPBOARDS come with a strong guarantee designed to protect you as our valued customer. ZEMPIRE will repair or replace this product, should it fail due to faulty materials or manufacture for a period of 2 years from the date of purchase.

For a full explanation of what is covered under this warranty please refer to our website www.zempire.co.nz/warranty.

Care & Safety information:

- Do not stand on your table.
- Be gentle with zips; always use two hands to close the zip; do not force it if zip gets caught.
- Do not use near open flame.
- Clean thoroughly after each use. Wash by hand with warm water and a soft towel or sponge.
- Do not use harsh cleaning chemicals.
- Leave the table to dry out completely before putting it away.
- Do not keep the table in direct sunlight or leave it in the rain.
- Store away from chemicals and moisture.
- In case re-coating is required; sand lightly with an extra fine-grit sandpaper. Reseal surface with a few coats of wood sealer product for ample water protection.